



☒☒

☒☒☒☒100☒

☒☒

61 0899 139



☒☒☒☒  
☒☒mm☒  
☒☒AWG☒  
☒

CuZn (Messing)  
1.50 mm<sup>2</sup>  
16  
100 Stk.



- 09 0204 00 07 - ☒☒☒☒ 6+PE, ☒☒☒☒
- 09 4204 00 07 - ☒☒☒☒ 6+PE, ☒☒☒☒, VDE-, UL-☒ SEV ☒☒
- 09 6492 000 05 - ☒☒☒☒
- 09 6492 200 05 - ☒☒☒☒
- 09 6504 000 08 - ☒☒☒☒
- 09 6504 200 08 - ☒☒☒☒
- 09 6520 000 12 - ☒☒☒☒
- 09 6520 200 12 - ☒☒☒☒
- 79 0232 20 04 - ☒☒☒☒☒
- 79 0234 20 04 - ☒☒☒☒
- 79 0236 20 07 - ☒☒☒☒☒
- 79 0238 20 07 - ☒☒☒☒
- 99 0202 00 07 - ☒☒☒☒☒ PG 9
- 99 0202 110 07 - ☒☒☒☒☒ PG 11
- 99 0202 15 07 - ☒☒☒☒☒ PG 13.5
- 99 0202 160 07 - ☒☒☒☒☒ PG 16
- 99 0202 210 07 - ☒☒☒☒, PG11
- 99 0202 215 07 - ☒☒☒☒, PG13.5
- 99 0202 70 07 - ☒☒☒☒ PG 9
- 99 0210 00 04 - ☒☒☒☒☒ PG 9
- 99 0210 110 04 - ☒☒☒☒☒ PG 11
- 99 0210 15 04 - ☒☒☒☒☒ PG 13.5
- 99 0210 160 04 - ☒☒☒☒☒ PG 16
- 99 0210 210 04 - ☒☒☒☒, PG11
- 99 0210 215 04 - ☒☒☒☒, PG13.5
- 99 0210 70 04 - ☒☒☒☒ PG 9
- 99 0214 00 07 - ☒☒☒☒☒ PG 9
- 99 0214 110 07 - ☒☒☒☒☒ PG 11
- 99 0214 15 07 - ☒☒☒☒☒ PG 13.5
- 99 0214 160 07 - ☒☒☒☒☒ PG 16
- 99 0214 210 07 - ☒☒☒☒, PG11



☒☒ ☒☒☒☒100☒  
☒☒ 61 0899 139

- 99 0214 215 07 - ☒☒☒☒, PG13.5
- 99 0214 70 07 - ☒☒☒☒ PG 9
- 99 0218 00 07 - ☒☒☒☒ PG 9
- 99 0218 110 07 - ☒☒☒☒ PG 11
- 99 0218 15 07 - ☒☒☒☒ PG 13.5
- 99 0218 160 07 - ☒☒☒☒ PG 16
- 99 0218 210 07 - ☒☒☒☒, PG11
- 99 0218 215 07 - ☒☒☒☒, PG13.5
- 99 0218 70 07 - ☒☒☒☒ PG 9
- 99 4202 00 07 - ☒☒☒☒ PG 9, VDE-, UL- ☒ SEV-☒☒
- 99 4202 110 07 - ☒☒☒☒ PG 11, VDE-, UL- ☒ SEV-☒☒
- 99 4202 14 07 - ☒☒☒☒ PG 13.5, VDE-, UL- ☒ SEV-☒☒
- 99 4202 160 07 - ☒☒☒☒ PG 16, VDE-, UL- ☒ SEV-☒☒
- 99 4202 210 07 - ☒☒☒☒, PG11, VDE-, UL☒SEV☒☒
- 99 4202 215 07 - ☒☒☒☒, PG13.5, VDE☒UL☒SEV☒☒
- 99 4202 70 07 - ☒☒☒☒ PG 9, VDE-, UL- ☒ SEV-☒☒
- 99 4218 00 07 - ☒☒☒☒ PG 9, VDE-, UL- ☒ SEV-☒☒
- 99 4218 110 07 - ☒☒☒☒ PG 11, VDE-, UL- ☒ SEV-☒☒
- 99 4218 14 07 - ☒☒☒☒ PG 13.5, VDE-, UL- ☒ SEV-☒☒
- 99 4218 160 07 - ☒☒☒☒ PG 16, VDE-, UL- ☒ SEV-☒☒
- 99 4218 210 07 - ☒☒☒☒, PG11, VDE-, UL☒SEV☒☒
- 99 4218 215 07 - ☒☒☒☒, PG13.5, VDE☒UL☒SEV☒☒
- 99 4218 70 07 - ☒☒☒☒ PG 9, VDE-, UL- ☒ SEV-☒☒
- 99 4222 00 04 - ☒☒☒☒ PG 9, VDE-, UL- ☒ SEV-☒☒
- 99 4222 110 04 - ☒☒☒☒ PG 11, VDE-, UL- ☒ SEV-☒☒
- 99 4222 160 04 - ☒☒☒☒ PG 16, VDE-, UL- ☒ SEV-☒☒
- 99 4222 210 04 - ☒☒☒☒, PG11, VDE-, UL☒SEV☒☒
- 99 4222 215 04 - ☒☒☒☒, PG13.5, VDE☒UL☒SEV☒☒
- 99 4222 70 04 - ☒☒☒☒ PG 9, VDE-, UL- ☒ SEV-☒☒
- 99 4226 00 07 - ☒☒☒☒ PG 9, VDE-, UL- ☒ SEV-☒☒
- 99 4226 110 07 - ☒☒☒☒ PG 11, VDE-, UL- ☒ SEV-☒☒
- 99 4226 14 07 - ☒☒☒☒ PG 13.5, VDE-, UL- ☒ SEV-☒☒
- 99 4226 160 07 - ☒☒☒☒ PG 16, VDE-, UL- ☒ SEV-☒☒
- 99 4226 210 07 - ☒☒☒☒, PG11, VDE-, UL☒SEV☒☒
- 99 4226 215 07 - ☒☒☒☒, PG13.5, VDE☒UL☒SEV☒☒
- 99 4226 70 07 - ☒☒☒☒ PG 9, VDE-, UL- ☒ SEV-☒☒
- 99 6490 000 05 - ☒☒☒☒
- 99 6502 000 08 - ☒☒☒☒
- 99 6518 000 12 - ☒☒☒☒