




☒

☒☒☒☒50 ☒☒☒☒

☒

61 0800 098 00



☒☒☒☒

☒☒☒☒

☒☒☒☒

☒☒☒☒

☒☒☒mm☒

☒☒☒AWG☒

☒☒☒☒

☒☒☒☒

☒☒☒☒

☒

1,5 mm

1,0 - 2,0 mm

CuSn (Bronze)

Au (Gold)

0.14 - 0.25 mm²

26 - 24

0,9 - 1 mm

DIN EN 60352-2: 24 N

50 Stk.



- 09 0101 19 02 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0101 25 02 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0101 70 02 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0101 79 02 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0102 25 02 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0102 70 02 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0102 79 02 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0105 19 03 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0105 25 03 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0105 70 03 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0105 79 03 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0106 19 03 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0106 25 03 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0106 70 03 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0106 79 03 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0109 19 04 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0109 25 04 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0109 70 04 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0109 79 04 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0110 19 04 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0110 25 04 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0110 70 04 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0110 79 04 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0111 700 04 - ☒☒☒☒, ☒☒
- 09 0111 780 04 - ☒☒☒☒, ☒☒, ☒☒☒☒☒
- 09 0112 700 04 - ☒☒☒☒, ☒☒



☒ ☒☒☒☒50 ☒☒☒☒

☒ ☒ 61 0800 098 00

- 09 0112 780 04 - ☒☒☒☒, ☒☒, ☒☒☒☒☒☒
- 09 0113 19 05 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0113 25 05 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0113 70 05 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0113 79 05 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0114 19 05 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0114 25 05 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0114 70 05 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0114 79 05 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0115 700 05 - ☒☒☒☒, ☒☒
- 09 0115 780 05 - ☒☒☒☒, ☒☒, ☒☒☒☒☒☒
- 09 0116 700 05 - ☒☒☒☒, ☒☒
- 09 0116 780 05 - ☒☒☒☒, ☒☒, ☒☒☒☒☒☒
- 09 0117 19 05 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0117 25 05 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0117 70 05 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0117 79 05 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0118 19 05 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0118 25 05 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0118 70 05 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0118 79 05 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0121 19 06 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0121 25 06 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0121 70 06 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0121 79 06 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0122 19 06 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0122 25 06 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0122 70 06 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0122 79 06 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0123 700 06 - ☒☒☒☒, ☒☒
- 09 0123 780 06 - ☒☒☒☒, ☒☒, ☒☒☒☒☒☒
- 09 0124 700 06 - ☒☒☒☒, ☒☒
- 09 0124 780 06 - ☒☒☒☒, ☒☒, ☒☒☒☒☒☒
- 09 0125 19 07 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0125 25 07 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0125 70 07 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0125 79 07 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0126 19 07 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0126 25 07 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0126 70 07 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0126 79 07 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0127 700 07 - ☒☒☒☒, ☒☒
- 09 0127 780 07 - ☒☒☒☒, ☒☒, ☒☒☒☒☒☒
- 09 0128 700 07 - ☒☒☒☒, ☒☒
- 09 0128 780 07 - ☒☒☒☒, ☒☒, ☒☒☒☒☒☒
- 09 0129 25 12 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0129 70 12 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0130 25 12 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0130 70 12 - ☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0133 70 02 - ☒☒☒☒, ☒☒☒☒ 4-6 mm, ☒☒☒☒
- 09 0133 72 02 - ☒☒☒☒, ☒☒☒☒ 6-8 mm, ☒☒☒☒
- 09 0133 78 02 - ☒☒☒☒, ☒☒☒☒ 6-8 mm, ☒☒☒☒
- 09 0133 79 02 - ☒☒☒☒, ☒☒☒☒ 4-6 mm, ☒☒☒☒
- 09 0134 70 02 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm, ☒☒☒☒
- 09 0134 72 02 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm, ☒☒☒☒
- 09 0135 70 03 - ☒☒☒☒, ☒☒☒☒ 4-6 mm, ☒☒☒☒
- 09 0135 72 03 - ☒☒☒☒, ☒☒☒☒ 6-8 mm, ☒☒☒☒
- 09 0135 78 03 - ☒☒☒☒, ☒☒☒☒ 6-8 mm, ☒☒☒☒
- 09 0135 79 03 - ☒☒☒☒, ☒☒☒☒ 4-6 mm, ☒☒☒☒
- 09 0136 70 03 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm, ☒☒☒☒
- 09 0136 72 03 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm, ☒☒☒☒
- 09 0136 78 03 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm, ☒☒☒☒
- 09 0136 79 03 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm, ☒☒☒☒
- 09 0137 70 04 - ☒☒☒☒, ☒☒☒☒ 4-6 mm, ☒☒☒☒
- 09 0137 72 04 - ☒☒☒☒, ☒☒☒☒ 6-8 mm, ☒☒☒☒
- 09 0137 78 04 - ☒☒☒☒, ☒☒☒☒ 6-8 mm, ☒☒☒☒
- 09 0137 79 04 - ☒☒☒☒, ☒☒☒☒ 4-6 mm, ☒☒☒☒
- 09 0138 70 04 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm, ☒☒☒☒
- 09 0138 72 04 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm, ☒☒☒☒
- 09 0138 78 04 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm, ☒☒☒☒



☒ ☒☒☒☒50 ☒☒☒☒

☒☒ **61 0800 098 00**

- 09 0327 780 07 - ☒☒☒☒☒☒☒☒, ☒☒, ☒☒☒
- 09 0328 700 07 - ☒☒☒☒☒☒☒☒, ☒☒
- 09 0328 780 07 - ☒☒☒☒☒☒☒☒, ☒☒, ☒☒☒
- 09 0329 00 12 - ☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0329 02 12 - ☒☒☒☒, ☒☒☒☒ 6 - 7.8 mm
- 09 0330 00 12 - ☒☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0330 02 12 - ☒☒☒☒☒, ☒☒☒☒ 6-7.8 mm
- 09 0337 00 16 - ☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0337 02 16 - ☒☒☒☒, ☒☒☒☒ 6 - 7.8 mm
- 09 0338 00 16 - ☒☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0338 02 16 - ☒☒☒☒☒, ☒☒☒☒ 6-7.8 mm
- 09 0341 00 14 - ☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0341 02 14 - ☒☒☒☒, ☒☒☒☒ 6 - 7.8 mm
- 09 0342 00 14 - ☒☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0342 02 14 - ☒☒☒☒☒, ☒☒☒☒ 6-7.8 mm
- 09 0343 00 19 - ☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0343 02 19 - ☒☒☒☒, ☒☒☒☒ 6 - 7.8 mm
- 09 0344 00 19 - ☒☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0344 02 19 - ☒☒☒☒☒, ☒☒☒☒ 6-7.8 mm
- 09 0345 02 24 - ☒☒☒☒, ☒☒☒☒ 6 - 7.8 mm
- 09 0346 02 24 - ☒☒☒☒☒, ☒☒☒☒ 6-7.8 mm
- 09 0451 25 14 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0451 70 14 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0452 70 14 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0461 25 19 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0461 70 19 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0462 25 19 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0462 70 19 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0473 700 08 - ☒☒☒☒, ☒☒
- 09 0473 780 08 - ☒☒☒☒☒☒☒☒, ☒☒, ☒☒☒
- 09 0474 700 08 - ☒☒☒☒☒☒☒☒, ☒☒
- 09 0474 780 08 - ☒☒☒☒☒☒☒☒, ☒☒, ☒☒☒
- 09 0495 25 24 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0495 70 24 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0496 25 24 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0496 70 24 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0505 25 16 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0505 70 16 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 09 0506 25 16 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0506 70 16 - ☒☒☒☒☒, ☒☒☒☒ 6-8 mm
- 09 0571 00 08 - ☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0571 02 08 - ☒☒☒☒, ☒☒☒☒ 6 - 7.8 mm
- 09 0571 09 08 - ☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0571 92 08 - ☒☒☒☒, ☒☒☒☒ 6 - 7.8 mm
- 09 0572 00 08 - ☒☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0572 02 08 - ☒☒☒☒☒, ☒☒☒☒ 6-7.8 mm
- 09 0572 09 08 - ☒☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 0572 92 08 - ☒☒☒☒☒, ☒☒☒☒ 6-7.8 mm
- 09 0581 25 07 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 0582 25 07 - ☒☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 09 1581 00 07 - ☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 1582 00 07 - ☒☒☒☒☒, ☒☒☒☒ 3,0 - 6,0 mm
- 09 6491 000 05 - ☒☒☒☒
- 09 6492 000 05 - ☒☒☒☒
- 09 6492 200 05 - ☒☒☒☒
- 09 6503 000 08 - ☒☒☒☒
- 09 6504 000 08 - ☒☒☒☒
- 09 6504 200 08 - ☒☒☒☒
- 09 6519 000 12 - ☒☒☒☒
- 09 6520 000 12 - ☒☒☒☒
- 09 6520 200 12 - ☒☒☒☒
- 99 0101 106 02 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 99 0101 118 02 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 99 0101 75 02 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 99 0101 77 02 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 99 0102 106 02 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 99 0102 118 02 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm
- 99 0102 75 02 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 99 0102 77 02 - ☒☒☒☒, ☒☒☒☒ 6 - 8 mm
- 99 0105 106 03 - ☒☒☒☒, ☒☒☒☒ 4 - 6 mm



☒

☒☒☒☒50 ☒☒☒

☒

61 0800 098 00

99 6489 000 05 - ☒☒☒☒

99 6490 000 05 - ☒☒☒

99 6501 000 08 - ☒☒☒☒

99 6502 000 08 - ☒☒☒

99 6517 000 12 - ☒☒☒☒

99 6518 000 12 - ☒☒☒

